

PA-800 Rev 1

SMOKE DETECTION PANEL XL No.6 SCHEDULE 'B' (DUAL ADDRESS INPUTS)							
INPUT			OUTPUT				REMARKS
ADDRESS No. 1	ADDRESS No. 2	INITIATING DEVICES	RESULTING ADDRESS	ANNUNCIATOR MESSAGES	ACTIVATED RELAYS	ACTIVATED HVAC EQUIPMENT	
061104	061105	POX-31-131 INTERFACE MODULE TRX-2R-6-7	061130	SOL. VALVE DUMP 75 SOUTH TWR I	SPX-15-031 GROUP A	SOL. VALVE DUMP ACS-75-4 GROUP A	
061104	061106						
061107	061108				SPX-17-051 GROUP A	SOL. VALVE DUMP ACS-75-12 GROUP A	
061109	061110				SPX-16-041 GROUP A	SOL. VALVE DUMP ACS-75-8 GROUP A	
061201	061202				SPX-14-023 GROUP A	SOL. VALVE DUMP ACS-75-3 GROUP A	
061201	061203						
061204	061205				SPX-16-044 GROUP A	SOL. VALVE DUMP ACS-75-11 GROUP A	
061206	061207				SPX-15-034 GROUP A	SOL. VALVE DUMP ACS-75-7 GROUP A	
061208	061209				SPX-17-053 GROUP A	SOL. VALVE DUMP ACS-75-14 GROUP A	
061210	061211				SPX-18-061 GROUP A	SOL. VALVE DUMP ACS-75-16 GROUP A	
				GROUP A	POX-25-073 POX-25-074 POX-26-081 POX-26-082 POX-26-083 POX-26-084 POX-19-014 POX-20-021 POX-20-024 POX-21-031 POX-21-034 POX-22-041 POX-22-043 POX-23-051	RETURN AIR FAN ACR-75-7 SHUTDOWN RETURN AIR FAN ACR-75-8 RETURN AIR FAN ACR-75-9 RETURN AIR FAN ACR-75-10 RETURN AIR FAN ACR-75-11 RETURN AIR FAN ACR-75-12 SUPPLY FAN ACS-75-3 SUPPLY FAN ACS-75-4 SUPPLY FAN ACS-75-7 SUPPLY FAN ACS-75-8 SUPPLY FAN ACS-75-11 SUPPLY FAN ACS-75-12 SUPPLY FAN ACS-75-14 SUPPLY FAN ACS-75-16	

SMOKE DETECTION PANEL XL No.6 SCHEDULE 'B'				
INPUT			RESULTING ADDRESS	ANNUNCIATOR MESSAGES
ADDRESS No. 1	ADDRESS No. 2	INITIATING DEVICES		
061301	061302	POX-31-132 INTERFACE MODULE TRX-2R-6-8	061330	SOL VALVE DUMP 75 NORTH TWR I
061303	061304			
061305	061306			
061307	061308			
061309	061310			
061309	061311			
061401	061402			
061403	061404			
061405	061406			
061405	061407			
				GROUP B